



3013 E. 6th Street
Long Beach, CA 90814
562-756-7600
GreshamMarine.com

Gooseneck Installation

The top of the gooseneck is approximately 16" up from the bottom of the mast extrusion. (not the butt fitting).

Once the correct location has been determined, drill the four 3/16" holes and rivet the fitting into place.

