

3013 E. 6th Street Long Beach, CA 90814 562-756-7600 GreshamMarine.com

Classic Lido 14 Centerboard Hanger installation Instructions – Time: About 2 hours

- 1. Refer to the Lido 14 Class Measurement Certificate found on www.Lido14Class.com for any updated measurements.
- 2. To install the centerboard (C/B) hangers, the centerboard must be removed from the boat. The easiest way is with the boat in the water at the dock. The boat can also be flipped on its side using the mast as leverage and while on grass. It can also be flipped using the mast on the trailer, however damage may occur is not sufficiently padded against the trailer.
- 3. Remove the C/B cap by removing the four screws.
- 4. Remove the C/B blade by removing the two screws from the existing hangers.
- 5. Installing the new C/B hangers. The goal is to have the hangers slide down to the bottom of the C/B trunk with little effort. The Gresham Marine hangers come with the bolt and spacer cut slightly longer than needed, as each trunk may vary.
- 6. First try sliding the C/B hangers down into the C/B trunk. If they fit all the way, your good. If they stick going down, cut off about an 1/8" from the bolt and stainless tube and try it again. Repeat the process until the slide down without any resistance. The bolt should be even with the side of the hanger and not stick out.
- 7. Next, attach the C/B hangers to your C/B and insert into the C/B into the trunk. and replace the cap.



Any questions, please call Gresham Marine.