



3013 E. 6th Street  
Long Beach, CA 90814  
562-756-7600  
GreshamMarine.com

## **Mast Rake Settings**

### **Lido 14 Classic**

Connect a 50' measuring tape to the main halyard shackle and run it to the top of the mast. Measurements take into account a standard 1" shackle on the main halyard.

**Mast Forward Measurement:** 21' 2" forward at center. Weight should be even on both port & starboard shrouds. Measure to the top of the transom at center.

**Mast Aft Measurement:** 20' 3" back at center, mast weight on forestay keeping mast in center of boat. Shrouds will be loose at this time. Measure to the top of the transom at center.

**Side to Side Measurement:** Pull the mast so that the opposite shroud and forestay are tight. Measure down to where the shroud exits the deck. Repeat on the opposite side. Adjust the pins in the chain plate until the mast is in the middle of the boat.

### **Lido 14 6000 Series**

**Mast Aft Measurement:** Use a carpenter's square and place it evenly on the deck and against front of the mast. The rake should be 1-2 degrees aft of the square.

**Mast Forward Measurement:** This should be 7-8" of the mast forward position.